Start here.		<u></u>		
a) Risk	Assessment	Dunger Level	Supervision	Treventitive Measures,
Cutting tools	enerally on	В	.	Be careful that body parts aren't in the way of tools.
Burning hot mu	hands on	B	В	Wear glows and ensure the temporature of the metal is not aping to injure you.
	flicking you eye	В	(B	luewi safety Glassic
Diapping	bracket o	л В	β	Houdle bracket with core.