

Section II (continued)

---

**Question 19 (7 marks)**

- (a) Why is it recommended that the earth lead be removed first and replaced last when disconnecting or connecting an automotive battery? 1

*To prevent any sparks which could  
ignite hydrogen gas given off by battery*

---

---

- (b) What does CCA refer to in an automotive battery? 1


*cold cranking Amps*

---

**Question 19 continues on page 14**

Question 19 (continued)


- (c) This diagram shows some components in an electrical circuit.



Complete the table naming and describing the function of each numbered component.


Component	Name	Function
1	fuse	to prevent too much current flow
2	switch	to allow or break current flow
3	earth	completes connection & allows current flow

- (d) In the diagram below, draw lines to show how to connect the terminals to increase battery output voltage to 24 volts. 1



- (e) In the diagram below, draw lines to show how to connect the terminals to maintain battery output voltage at 12 volts. 1

*parallel*



**End of Question 19**